



PEDESTRIAN DIVERSION ROUTE

Information on Ordnance Survey mapping and the permission of the Controller of Her Majesty's Stationery Office, London, is hereby acknowledged. The Ordnance Survey map is reproduced by permission of the Controller of Her Majesty's Stationery Office, London. Ordnance Survey map number: OS 1000 1511, 2007.

THE INFORMATION CONTAINED HEREIN IS THE PROPERTY OF THE CONSULTANT AND IS NOT TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN PERMISSION OF THE CONSULTANT.

**SAFETY, HEALTH AND ENVIRONMENTAL NOTIFICATION**

This document is the property of the Consultant and is not to be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording, or by any information storage and retrieval system, without the written permission of the Consultant.

Authorisation / Comments:

Drawings / Revision:

**SCOPE OF WORKS**

- 1) REPAIR THE AREAS OF IMPACT DUE TO THE DIVERSION OF THE BRIDGE.
- 2) CLEAN UP RUST AND REPAIR ALL THE STEELWORK ON THE STRUCTURE.
- 3) CLEAN AND REPAIR THE REINFORCED CONCRETE PIER WHICH SUPPORTS THE STEEL PIER.
- 4) MAKE DOORS HERMETIC TO SOFT:
- 5) MAKE UP AND REPAIR APPROACHES TO THE BRIDGE TO REMOVE THE LOW SPOTS.
- 6) REPAIR ALL DAMAGED PARTS TO THE BRIDGE TO MAKE IT SAFE.
- 7) REPLACE ALL THE FALLED AREAS OF SURROUNDING TO THE BRIDGE.
- 8) APPLY ANTS-SMOKING TO THE WHOLE OF THE BRIDGE AREA.
- 9) INSTALL AN APPURTENANCE LIGHT DOWN THE CENTRE LINE OF THE MAIN SPAN.
- 10) REPAIR THE EXPANSION JOINTS AT THE FOOT OF THE BRIDGE PIER.
- 11) REMOVE THE RAINWATER DRAINAGE PIPES AT THE JOINT BETWEEN THE BOTTOM OF THE NORTH CAST AND THE FOOTWALL.
- 12) CLEAN OUT DRAINAGE CHANNELS.
- 13) GRASS AND MAKE GOOD BEHIND AND BETWEEN AND PROTECT FROM WATER INGRESS.
- 14) POLISH STAINLESS STEEL HANDRAILS.
- 15) MAKE REPAIRS TO THE ALUMINIUM WORK FOR LIGHTNING PROTECTION AND TO THE REINFORCED CONCRETE FOOTWALL.
- 16) REMOVE ALL LOFT FILLING, CLEAN REPAIR AND REWALL.
- 17) INVESTIGATE WATER INGRESS TO ROOM BELOW.



**URBANDIVISION**  
 Urban Design  
 11, The Quadrant, Salford, Greater Manchester, M6 7JG, UK  
 Tel: 0161 275 1234  
 Fax: 0161 275 1235  
 Email: info@urbandivision.co.uk  
 Website: www.urbandivision.co.uk

**URBAN DESIGN**  
 11, The Quadrant, Salford, Greater Manchester, M6 7JG, UK  
 Tel: 0161 275 1234  
 Fax: 0161 275 1235  
 Email: info@urbandivision.co.uk  
 Website: www.urbandivision.co.uk

**PROJECT**  
 TRINITY FOOTBRIDGE  
 REMEDIAL WORKS

**DATE**  
 12/2003

**SCALE**  
 1:500

**PROJECT NO.**  
 12903-02